INSTALLATION INSTRUCTION

SINGLE LEVER WASHBASIN MIXER


****ACCESSORIES CHECKING**

LIST OF THE STANDARD ACCESSORIES:

Please double-check the accessory list hereinafter and contact our company or our distributor for any unconformity.

Remarks:


- 1. Without affecting their performancing, accessories may be changed without further notice;
- 2.Drawings for reference only, Product size & shape refer to actual faucet.





Code	The Accessory List	Quantity
1	Main body	1
2	0-ring	1
3	Rubber washer	1
4	Clamp	1
5	Fixing bolt	1
6	Nut	1
7	Inlet pipe	2


%Installation Instructions

- ☆ Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory;
- ☆ To avoid the faucet from jamming,do flush the water pipe before installation;
- ☆ After installation,make sure every joint safely sealed & no leaking;
- ☆ Using condition:Working pressure at 0.05-1.0MPa(including cold & hot water pressure), with applicable water temperature:4°C-90°C;
- ☆ Make sure to connect the hot/cold inlet pipe correctly,if standing in front,hot water pipe connecting to the left & cold water pipe connecting to the right.










%Installation Procedures

- ☆ Make sure the installation holes to be in right size;
- ☆ Connect the main body & water supply pipe with water inlet pipe.



%Usage

☆How to operate the handle

- 1) Raise the handle up for opening water; push it down for close;
- 2) Turn the handle to the left to increase hot water flow for higher water temperature, and lower water temperature by operating reversely.

%Cleaning & Maintenance

- ☆ To keep the product clean & shining, follow the as below:
 - 1. Flush with clean water & dry with soft cloth only;
 - 2.If any dirt, clean with soft liquid or transparent glass detergent;
 - 3.Do not use any scrubbing detergent, polisher, sane-cloth, paper tissue or scraper;
 - 4.Do not use acid detergent, indissovable grain-like detergent or soap;
 - 5.Disassemble the aerator with a coin and clean it when necessary.

